


# Banshee™

## Set-up Instructions



Stake, four piece mast and banner (drop shape shown in example)



Place stake into ground. If required a hammer can be used to gently tap the stake into the ground.



Assemble mast. Thickest section to thinnest.



Slide Mast into pocket at bottom of banner. Bottom of banner will have a black tip of mast meets end of cord with a silver clip.



With mast inside banner, pull banner downward so mast meets end of banner pocket.



Slide banner over length of mast. Use your foot to brace the mast against the ground or floor.



Holding the banner in place with one hand, attach the silver clip to the eyelet on the mast.



Slide mast bottom over top of stake.



Lengthen or shorten cord length to adjust tension on banner as needed.




To break down, repeat steps in reverse. Use caution as the banner mast is now under tension.



From Left to Right

- Indoor foot
- Outdoor stake
- Mast in provided bag



Indoor stand replaces the stake. Spread feet so base appears as shown. Mast slides over top of indoor foot.

### PLEASE READ!

- Your Banshee banner may be one of 6 different available shapes
- The height of your banshee may be taller than shown here. Always pay attention to possible overhead wires
- Always make sure you are staking in in a safe area free of wires, sprinklers or other buried utilities.
- Banshees can be used indoors when the indoor folding base is used



Do not display your outdoor banners in extreme winds (24-31mpg or 6bt and higher) and / or thunderstorms. Do not use near overhead wires. Displaying in high winds or near overhead wires may result in property damage, injury or death and any and all existing warranties.

