



# euro It | *HYBRIDS*



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

# euro lt | HYBRIDS

## Using Your Setup Instructions

The Euro LT Hybrids Setup Instructions are created specifically for your configuration. They are laid out sequentially in levels, including exploded views, and a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.

## Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts, countertops, or panels use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.

## General Setup Instructions for Extrusion System



The Tool

Most exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Typical Connection

Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.



Typical Connection (cont'd)




Numbered Label

Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With extrusion components the labels contain Black numbers unless otherwise specified.




Horizontal Inline Connection (remove only one setscrew)

Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.



Base Plate Connection


Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.



Vertical Connection (remove only two setscrews)


When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller section which then require assembly.

Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.




Connector

Each component has 2 clips, the lower clip is ALWAYS black. The top clip is color coded to distinguish which level. The color coded clip also contains the numbered label.




Cut Away View Of Slide Clips

Components connect together by aligning them and sliding downward connecting clips together.



Example of Connection

Configurations are assembled from left to right, usually starting with #1 and following the numbered sequence.




Top View of Panels with Locks

The first level of components contain panel locks that are located at the top of the panel for extra stability and seamless connection. When disassembling panels twist top connection slightly and lift right panel upward.

**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**


866.652.2100

Item	Quantity	Description
1	2	Oval Base Plates
2	2	84" Square Vertical Extrusion
3	1	20.115" Tapered Horizontal Extrusion
4	1	20.115" Tapered Horizontal Extrusion
5	1	7.322" Horizontal Extrusion
6	1	7.322" Horizontal Extrusion
7	1	47.1923" Curved Extrusion w/ Attached Velcro to Back of Extrusion
8	1	47.1923" Curved Extrusion w/ Attached Velcro to Back of Extrusion
9	1	47.1923" Curved Extrusion w/ Attached Velcro to Back of Extrusion
10	1	47.1923" Curved Extrusion w/ Attached Velcro to Back of Extrusion
11	1	47.1923" Curved Extrusion w/ Attached Velcro to Back of Extrusion
12	1	47.1923" Curved Extrusion w/ Attached Velcro to Back of Extrusion
13	1	20.115" Tapered Horizontal Extrusion
14	1	20.115" Tapered Horizontal Extrusion



**Steps:**

- 1) Attach oval base plates [1] to vertical extrusions [2].
- 2) Attach tapered horizontal extrusions [3 and 4] to vertical extrusions [2].
- 3) Attach horizontal extrusions [5 and 6] to vertical extrusions [3], placing inserts between horizontal extrusions [3&5 and 4&6].
- 4) Assemble curved extrusion [7 and 8] together.
- 5) Attach each side of assembled curved extrusion to horizontal extrusions [3 and 4].
- 6) Attach curved extrusion [9] to top of curved extrusion [7] and to horizontal extrusion [5].
- 7) Attach curved extrusion [10] to top of curved extrusion [8] and to horizontal extrusion [6].
- 8) Attach curved extrusion [11] to top of curved extrusion [9].
- 9) Attach curved extrusion [12] between curved extrusions [11 and 10].
- 10) Attach tapered horizontal extrusion [13] between vertical extrusion [2] and curved extrusion [11], placing insert between horizontal extrusions [5 and 13].
- 11) Attach tapered horizontal extrusion [14] between vertical extrusion [2] and curved extrusion [12], placing insert between horizontal extrusions [6 and 14].
- 12) Attach graphic to Velcro on backside.








WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

Item Number	Description	Item Number	Description
1	34"w x 38"h Custom Flat Panel	8	34"w x 38"h Custom Flat Panel
2	11"w x 9.5"h Flat Panel	9	38"h 90° Corner Connector
3	34"w x 38"h Custom Flat Panel w/ Door	10	11"w x 38"h Flat Panel
4	38"h 90° Corner Connector	11	38"h 90° Corner Connector
5	11"w x 38"h Flat Panel	12	34"w x 38"h Custom Flat Panel w/ Door
6	38"h 90° Corner Connector	13	11"w x 9.5"h Flat Panel
7	Custom Curved Panel	14	Custom Curved Panel

Steps:

Assemble panels in numerical order starting with #1. \*






\* = Pin Location

**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**

Item	Quantity	Description
A	1	39" Round formed extrusion
AB	1	39" Round formed extrusion
B	1	39" Round fomred extrusion
C	1	39" Round formed extrusion
CD	1	39" Round formed extrusion
D	1	39" Round formed extrusion
E	2	14" Round extrusion
F	1	14" Round extrusion

Steps:

- 1) Connect 39" (A) round formed extrusion to 39" (A) round formed extrusion.
- 2) Connect 39" (B) round formed extrusion to 39" (B) round formed extrusion.
- 3) Connect 39" (C) round formed extrusion to 39" (C) round formed extrusion.
- 4) Connect 39" (D) round formed extrusion to 39" (D) round formed extrusion.
- 5) Connect (A) round formed extrusion and (D) round formed extrusion to 14" (E) extrusion.
- 6) Connect (B) round formed extrusion and (C) round formed extrusion to 14" (E) extrusion.
- 7) Connect (AB) round formed extrusion and (CD) round formed extrusion to 14" (F) extrusion.
- 8) Attach Canopy Assembly to Vertical extrusions with Canopy attachments.





**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**

866.652.2100

Item	Qty.	Description
16	1	Base Plate
17	1	35.25" h Curved Vertical Extrusion w/ Attached Pins
18	1	35" h Round Vertical Extrusion


Steps:

- 1) Attach round vertical extrusion [18] to base plate [16], see DetailD on General Information Page.
- 2) Slide large counter on vertical extrusion [18] and slide curved vertical extrusion [17] thru counter hole from bottom and attach to base plate [16].
- 4) Secure large counter to vertical extrusion [18] with thumbscrews.
- 5) Set small counter atop vertical extrusion [17], and secure with thumbscrews to vertical extrusion [18].




\* = Thumbscrew Location

**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**



Tub Front View



**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**